

Diagram of the front panel of the CQ0A computer. The panel features a central display area with 12 slots, each containing a small screen showing a number and a character. To the left of the display is a large, stylized 'E' shape. To the right is a control panel with a circular dial and a rectangular button. The text 'ENTREE FILS' is visible on the left side of the panel.

Slot	Top	Bottom
7	7	
8	60CC	X
9	9	
10	10	
11	148B	X
12	148A	X
1	1	MA
2	2	NO
3	13AD	X
4	4	
5	148C	X
6	148D	X